



1、PRESSER FOOT AND OUTER ATTACHMENTS



图一

Item	Part No.	Description	Qty	Item	Part No.	Description	Qty
1	801-1-1	Presser bar adjusting screw	1	28	801-1-28	Flat screw	
2	801-1-2	Press bar lifter bracket	1	29	801-1-29	Ruler set screw	1
3	801-1-3	Presser bar lifter rbracket screws	2	30	801-1-30	Ruler set screw washer	
4	801-1-4	Press bar lifer pin	1	31	801-1-31	Ruler	
5	801-1-5	Presser bar lifter	1	32	801-1-32	Slide plate screws	6
6	801-1-6	Presser bar lifter lever	1	33	801-1-33	Slide plate screws	2
7	801-1-7	Presser bar cover screw	1	34	801-1-34	Slide plate A	1
8	801-1-8	Presser bar spring	1	35	801-1-35	Slide plate B	1
9	801-1-9	Presser bar	1	36	801-1-36	Slide plate C	1
10	801-1-10	Presser foot side plates	2	37	801-1-37	Waste feeder screw	1
11	801-1-11	Presser footside platesadjusting screw	4	38	801-1-38	Waste feeder stop pin	1
12	801-1-12	Presser footside plate screw	1	39	801-1-39	Hexagon slotted screw(base plate)	2
13	801-1-13	Prsser foot shaft hook metal hing screw	1	40	801-1-40	Bed	1
14	801-1-14	Prsser foot shaft hook metal set screw	1	41	801-1-41	Belt cover plate	1
15	801-1-15	Prsser foot shaft hook metal	1	42	801-1-42	Belt cover plate screw	1
16	801-1-16	Presser foot	1	43	801-1-43	Belt cover lid	1
17	801-1-17	Oil cap	1	44	801-1-44	Belt cover lid spopper	1
18	801-1-18	Arm	1	45	801-1-45	Ruler set screws	1
19	801-1-19	Presser foot adjusting screw	1	46	801-1-46	Hinges	1
20	801-1-20	Presser foot adjustable screw nuts	2	47	801-1-47	Hinges pins	2
21	801-1-21	Presser bar spring pin	1	48	801-1-48	Hinge set screw washers	2
22	801-1-22	Presser foot spring	1	49	801-1-49	Hinge set screws	4
23	801-1-23	Inner hexagon screw	1	50	801-1-50	Waste feeder metals(set)	4
24	801-1-24	Tape pin	1	51	801-1-51	Transnission shaft	1
25	801-1-25	Presser foot spring screw	1	52	801-1-52	Base plate	1
26	801-1-26	Presser foot shaft	1	53	801-1-53	Set screw(transmission shaft)	2
27	801-1-27	Worm chamber plate	1	54	801-1-53	Tape pin	4

2、KNIFE AND RELATED PARTS



图二

Item	Part No.	Description	Qty
1	801-2-1	Leather peeler cover	1
2	801-2-2	Knife ste screws	4
3	801-2-3	Knife	1
4	801-2-4	Knife shafe	1
5	801-2-5	Knife shafe key	1
6	801-2-6	Knife shaft nuts	2
7	801-2-7	Bearing	1
8	801-2-8	Rubber bushings	2
9	801-2-9	Pulley shaft flange holder	1
10	801-2-10	Pulley shaft flange	1
11	801-2-11	Flange shafts	2
12	801-2-12	Pulley shaft flange nut	1
13	801-2-13	Pulley shaft flange screw(b)	2
14	801-2-14	Pulley shaft flange screw(a)	2
15	801-2-15	Pulley shaft dey(small)	1
16	801-2-16	Pulley shaft	1
17	801-2-17	Pulley shaft key(large)	1
18	801-2-18	Hexagonalnut(a)	1
19	801-2-19	Knife shaft keg screws	2
20	801-2-20	Cluch lever spring screw	1
22	801-2-22	Clutch lever	1
23	801-2-23	Knife shaft lead pipe dey	1
24	801-2-24	Knife shaft lead pipe	1


Item	Part No.	Description	Qty
25	801-2-25	Knife shaft worm wheel	
26	801-2-26	Knife shaft worm	
27	801-2-27	Tape pin	1
28	801-2-28	Knife adjusting knob	1
29	801-2-29	Knife adjusting handle	1
30	801-2-30	Knife adjusting handle knob	1
31	801-2-31	Pulley shaft bearings	3
32	801-2-32	Pulley shaft metal	1
33	801-2-33	Pulley shaft metal screws	1
35	801-2-35	Clutch	1
36	801-2-36	Pulley	1
37	801-2-37	Clutch side block	1
38	801-2-38	Clutch side block screw	1
39	801-2-39	Clutch arm	1
40	801-2-40	Clutch spring	1
41	801-2-41	Clutch spring hook	1
42	801-2-42	Clutch side block screw nut	1
43	801-2-43	Clutch lever screw	1
44	801-2-44	Clutch lever shaft	1
45	801-2-45	Clutch arm screw	1
46	801-2-46	Clutch arm spring	1
47	801-2-47	Clutch lever spring waser	1
48	801-2-48	Clutch lever spring hinge screw	1

3. GRINDSTONE AND ROLLER RELATED PARTS

Ltem	Part No.	Description	Qty
1	801-3-1	Warm wheel box	1
2	801-3-2	Main shft worm gear wheel	1
3	801-3-3	Main shft worm gear	1
4	801-3-4	Roller diving shaft meal(1)	1
5	801-3-5	Roller diving shaft metal(2)	1
6	801-3-6	Main shft worm gear wheel screw	1
7	801-3-7	Main shft worm gear wheel chamber cover screw	1
8	801-3-8	Main shaft front bushing	1
9	801-3-9	Main shaft worm gear chamber oil seal	1
10	801-3-10	Main shaft worm gear chamber screw	1
11	801-3-11	Main shaft key(1)	1
12	801-3-12	Main shaft	1
13	801-3-13	Main shaft key(2)	1
14	801-3-14	Main shaft bearing	1
15	801-3-15	Main shaft deaning holder screw	1
16	801-3-16	Main shaft pulley	1
17	801-3-17	Hexagonal unt B	1
18	801-3-18	Main shaft belt	1
19	801-3-19	Grindstone set screw	1
20	801-3-20	Grindstone set screw unt	1
21	801-3-21	Grindstone	1
22	801-3-22	Grindstone shaft	1
23	801-3-23	Grindstone shaft pulley	1
24	801-3-24	Grindstone shaft pulley taper pin	1
25	801-3-25	Grindstone shaft bearing	2
26	801-3-26	Grindstone shaft bracket	1
27	801-3-27	Grindstone shaft bearing roller	1
28	801-3-28	Grindstone shaft bracket arm	1
29	801-3-29	Grindstone shaft bracket arm center screw nat	3
30	801-3-30	Grindstone shaft bracket arm ceter screws	3
31	801-3-31	Grindstone shaft bracket arm spring	1
32	801-3-32	Grindstone shaft bracket arm spring screws	2
33	801-3-33	Grindstone shaft bracket screw	1
34	801-3-34	Grindstone adjusting screw pipe nuts	1
35	801-3-35	Grindsone adjusting screw pipe	1
36	801-3-36	Grindstone adjusting screw	1
37	801-3-37	Grindstone shaft belt	1
38	801-3-38	Belt guide pulley screws	2
39	801-3-39	Belt guid pulley shafts	2
40	801-3-40	Belt guid pulley bearing	4
41	801-3-41	Belt guid pulleys	2
42	801-3-42	Belt guid pulley washers	2

Ltem	Part No.	Description	Qty
43	801-3-43	Belt guide pulleg shaft surews	3
44	801-3-44	Belt guide bracket	1
45	801-3-45	Belt guide bracket	1
46	801-3-46	Belt guide bracket string	1
47	801-3-47	elt guide bracket shaft	1
48	801-3-48	Belt guide bracket turing stoppers	2
49	801-3-49	Roller driving shaft	1
50	801-3-50	Roller driving shaft key	1
51	801-3-51	Roller driving shaft joint	1
52	801-3-52	Roller shaft oik wick	1
53	801-3-53	Roller shaft	1
54	801-3-54	Roller shaft oil seal plug	1
55	801-3-55	Roller	1
56	801-3-56	Roller washer	1
57	801-3-57	Roller bracket	1
58	801-3-58	Roller shaft screw	1
59	801-3-59	Waste clear metal shaft screw	1
60	801-3-60	Roller bracket arm spring hooks(2)	1
61	801-3-61	Roller bracket arm spring	1
62	801-3-62	Roller bracket arm spring hooks metal	1
63	801-3-63	Roller bracket arm	1
64	801-3-64	Roller bracket arm adjusting screw	1
65	801-3-65	Roller bracket arm adjusting screw	1
66	801-3-66	Roller bracket arm spring hooks(1)	2
67	801-1-19	Roller bracket turning arm adjusting screw	1
68	801-1-20	Roller bracket turning arm adjusting screw nut	1
69	801-3-69	The rotary arm	1
70	801-3-70	Roller bracket turning arm	1
71	801-3-71	Roller bracket turning arm spring stopper	1
72	801-3-72	Roller bracket turning arm spring adjusting nut	2
73	801-3-73	Roller bracket turning arm spring adjusting screw	1
74	801-1-53	Set screw	1
75	801-3-75	Roller bracket arm center pin	1
76	801-3-76	Roller bracket arm cmter pin screw	1
77	801-3-77	Waste cler metal leather unts	2
78	801-3-78	Waste clear metal	1
79	801-3-79	Waste clear metal leather	1
80	801-3-80	Waste clear metal leather screws	2
81	801-3-81	Waste clear metal spring	1
82	801-3-82	Waste clear metal shaft	1
83	801-3-83	Tape pin	1
84	801-3-84	Roller shaft screw	1

3. GRINDSTONE AND ROLLER RELATED PARTS



图三

